

Figure: 30 TAC §217.92(f)

**Equation D.2.**

$$Q = (A \times N) + B$$

Where:

Q = Design flow rate (gallons per minute)

A = Design coefficient, typically 0.5

N = Number of equivalent dwelling units served by the off-site component

B = Safety factor, assumed to be 20.0