

Figure: 30 TAC §217.164(c)(4)

Equation F.5.

$$SRT = \frac{SF}{0.47 e^{0.098(T-15)}, \text{days}^{-1}}$$

Where:

SF = safety factor

$0.47e^{0.098(T-15)}$ = maximum growth rate (days^{-1})
T = temperature T ($^{\circ}\text{C}$)